


**gruppo telaio inferiore**

**pag. A**

pos.	codice	pos.	codice
1	LE200112	11	PASS200101EC
2	LE3240D90	12	LE20M000
3	TSLE2000	13	LE20001AC
4	LE3240D90	14	ASP00000
5	PASS200101DC	15	LE200113
6	LE20001FC	16	-
7	LE20001CX	17	-
8	PASS0120	18	-
9	FRA00000	19	-
10	RPPG0000	20	-




**gruppo bobina**

**pag.**

**B**

pos.	codice	pos.	codice
1	BA900200	11	LE200005
2	PASS200103AC	12	F1625000
3	PASS035C	13	601320
4	PASS035B	14	PASS0130
5	PASS035A	15	LE20003AC
6	261000	16	PASS200103CX
7	F1625000	17	PASS006BL20
8	601320	18	PASS006A
9	LE200004	19	-
10	F1625000	20	-




**gruppo turbina**

**pag.**

**C**

pos.	codice	pos.	codice
1	RCL901/4-10	11	FZ100012
2	MV14MF00	12	600220
3	LE200006	13	F1625000
4	RCL901/4-10	14	LE200008
5	F35100002	15	BA901210
6	LE200009	16	-
7	F1625000	17	-
8	601320	18	-
9	PM40/820	19	-
10	LE200007	20	-




**gruppo arresto**

**pag.**

**D**

pos.	codice	pos.	codice
1	TALE2000	11	-
2	1262033	12	-
3	BA900200	13	-
4	N3/4-1/2	14	-
5	LE200002	15	-
6	VIM12L20	16	-
7	600220	17	-
8	F1625000	18	-
9	LE200009	19	-
10	LE20ND10	20	-




**gruppo carrello**

**pag.**

**E**

pos.	codice	pos.	codice
1	LE20F000	11	-
2	F1625000	12	-
3	COP15000	13	-
4	RPPP0000	14	-
5	-	15	-
6	-	16	-
7	-	17	-
8	-	18	-
9	-	19	-
10	-	20	-



**gruppo irrigatore**

**pag.**

**F**

pos.	codice	pos.	codice
1	30235	17	30337
2	30236	17a	30248
3	30238	18	30249
4	30239	20	30250
6	30389	21	30251
7	30241	22	30252
8	30242	23	30314
9	30243	25	30253
10	30244	29 30	30254
11	30245	31	30256